



## Music Box Duck Dance

*Assembly instruction*

## Spieluhr Ententanz

*Aufbauanleitung*

## Boîte à musique Danse des canards


*Notice de montage*

## Carillon Ballo delle papere

*Istruzioni di montaggio*


## Caja musical Baile de patos

*Instrucciones de montaje*




Art. Nr. 7489


①



180°



②



180°

=

